

**EPIC (all variants)**  
**Instructions for use**

This product is equipped according to version with:

- Two lever multilock mechanism
- One lever tilting mechanism
- Autoreturn mechanism without lever



**Two lever multilock mechanism:**

**Seat height control:** pull the right lever under the seat upward and release the piston in the desired height position.

**Tilting adjustment:** pull the left lever under the seat to unlock tilting mechanism. Choose required position and pull the left lever back. Mechanism will lock in the nearest possible position.

**Tilting strenght adjustment:** turn the handle on the right lever to adjust the strength of the tilting.

**One lever tilting mechanism:**

**Seat height control:** pull the lever under the seat upward and release the piston in the desired height position.

**Autoreturn mechanism:**


This mechanism is not equipped with any control levers. The seat will automatically return to the default position after leaving the chair.

---

**Care and Maintenance**

- To avoid possible personal injury, ensure all screws are fully tightened before using the chair. Periodically check the screws and ensure that they remain fully tightened.
- The chair is designed to a normal use in office environment, 8 hours a day. Warranty 36 months is valid only for this type of use. During the warranty period the manufacturer will replace any parts that present a defect.
  - The maximum capacity of the chair is 120 kg.

**EPIC (all variants)**  
**Assembly instruction**  
**Instrukce k montáži**



U verze CONFERENCE je židle vybavena 4 rameným křížem a kluzáky.  
Version CONFERENCE is equipped with 4-spoke base with plastic feet.