


# PRODUKTOVÝ LIST

## Flex Wall Střední

FLW-M




- Nastavitelná výška a šířka pomocí teleskopických tyčí
- Velmi lehká konstrukce, díky čemuž je snadno přemístitelná z místa na místo
- Skvělé promo pozadí, které neuškodí žádnému rozpočtu

# PRODUKTOVÝ LIST

## Flex Wall Střední

FLW-M



# PRODUKTOVÝ LIST

## Flex Wall Střední

FLW-M

### ZÁKLADNÍ INFORMACE

SKU	Rozměry (mm) (A x B x C)	Formát (mm)	Viditelná část (mm) (VXxVY)	Rozteč otvorů (mm) (XxY)
FLW-M	2500 x 2500 x 440	2400 x 2350 mm	2400 x 2350 mm	-

Orientace	Váha (kg)
Na výšku	5,00

### ELEKTRICKÉ PARAMETRY

Osvětlení	Osvětlení barva (K)	Svitivost (cd)	Světelná intenzita (lx)	Příkon (W)
Ne	-	-	-	-

### BALENÍ

Balící jednotka 1 (mm)	Balící jednotka 2 (mm)	Balící jednotka 3 (mm)
1370 x 115 x 115	-	-

Paleta počet ks	Váha palety (kg)	Typ palety
60	372	-

### DALŠÍ INFORMACE


Certifikace výrobku	EAN
Ne	8596052144608

# MONTÁŽNÍ NÁVOD


## Flex Wall Střední

FLW-M

❶ Screw two vertical bars with bases




❷ Adjust the length of two horizontal bars to fit for the graphic




❸ Put on the graphic with two horizontal bars




❹ Connect the bottom horizontal bar with Vertical one by screwing.



❺ Connect the upper horizontal bar with Vertical one by screwing.



❻ Rotate two vertical bars to fit for the graphic by height adjustment.



Disassemble in the reverse order.

Caution: Make sure the graphic is folded neatly and save it in bag after using, to avoid wrinkle.

... FLEXWALL